



INNOVATIVE SILICONE SPECIALTIES



### **Spray on Detangler** **Formulation FH200**

<b><u>Phase</u></b>	<b><u>Ingredient</u></b>	<b><u>INCI Name</u></b>	<b><u>%w/w</u></b>
<b>Part A</b>	Water	Aqua	97.65
	<b>Silsurf J208-112 (Siltech)</b>	<b>Lauryl PEG-8 Dimethicone</b>	1.50
	Siugaquat S1210	APG Quat	0.50
	Fragrance		0.20
	Kathon CG		0.005
	Na <sub>2</sub> EDTA		0.10
<b>Part B</b>	Citric Acid		<b>to pH 6</b>
			<b><u>100.00</u></b>

#### **Procedure:**

Mix all ingredients until uniform. Adjust pH with Citric Acid.

*Technical information contained herein is believed to accurate. However, it is furnished without charge or obligation and is given and accepted at the recipient's sole risk. No guarantee of the accuracy of the information is made and the products discussed are sold without conditions or warranties expressed or implied. Purchasers should make their own tests and determine suitability of the product for their particular purposes. Nothing contained herein shall be considered a recommendation for any use that may infringe upon patent rights.*

© Siltech LLC 2005      All Rights Reserved



Siltech Personal Care  
678 442 0210  
[www.siltechpersonalcare.com](http://www.siltechpersonalcare.com)