



INNOVATIVE SILICONE SPECIALTIES



Anhydrous Makeup Formulation FM603

| <u>Phase</u> | <u>Ingredient</u> | <u>%w/w</u> |
|---------------------|--------------------------|----------------------|
| Part A | Resin 12029 | 4.25 |
| | Ozokerite 1020P | 10.00 |
| | Silsurf J208-612 | 2.50 |
| | Siltech F-0.65 | 23.75 |
| | Siltech CF-955 | 30.00 |
| Part B | Mica 280 | 2.50 |
| | Titanium Dioxide | 19.08 |
| | Yellow Iron Oxide | 1.80 |
| | Red Iron Oxide | 0.54 |
| | Black Iron Oxide | 0.18 |
| | Excel Talc | <u>5.40</u> |
| | | <u>100.00</u> |

Procedure:

1. Mix Resin, Ozokerite, Silsurf J208-612, Siltech F-0.65 and Siltech CF-955.
2. Heat to 75-80°C until wax is completely melted.
3. Add Pigments, Maintain temperature at 75°C until Pigments are completely dispersed.
4. Cool to 60°C and pour.

Notes:

- A. The texture of this formula can be adjusted. It may be softened by lowering the Ozokerite as low as 6%.
- B. The resin provides long wear properties.
- C. The Silsurf J208-612 is very effective in dispersing the pigments in the silicone base.

Technical information contained herein is believed to accurate. However, it is furnished without charge or obligation and is given and accepted at the recipient's sole risk. No guarantee of the accuracy of the information is made and the products discussed are sold without conditions or warranties expressed or implied. Purchasers should make their own tests and determine suitability of the product for their particular purposes. Nothing contained herein shall be considered a recommendation for any use that may infringe upon patent rights.

